





AWNING CLIP STANDARD LOCATION STARTS WITH 2 ON EACH HEAD AND SILL.
AS THE FIELD GROWS ADD CLIPS
SPANNING NO GREATER THAN 16" APART

## **IMPORTANT:**

- CLIPS SHOULD NOT INTERFERE WITH ANY HARDWARE OPERATION. HARDWARE MAY CAUSE CLIP LOCATIONS TO BE DIFFERENT FROM FIELD TO FIELD DEPENDING ON FAV AND HARDWARE POSITIONS.
- ALL CLIPS SHOULD BE MIRRORED AND PARRALEL FROM HEAD TO HEAD AND JAMB TO JAMB.
- CRITICAL TOLERANCE FOR  $\frac{1}{2}$ " FRAME TO CLIP LOCATION IS +OR- $\frac{1}{32}$ " NO EXEPTIONS.

ROUTINELY CHECK THAT CLIPS REMAIN SECURE, REPLACE AS NESSESARY.

TOLERANCE	DRAWN msaldana			6/19/2018		
$\frac{\text{DECIMAL}}{\text{X.X} \pm 0.100}$	CHECKED					1
X.XX ± 0.025	APPROVED				1	
X.XXX ± 0.005 FRACTIONAL	<sup>SIZE</sup> B	SCALE :	1/4	SHEET	1 of 1	]3
$X/X \pm 1/32$	PRODUCT FAMILY					ľ
ANGULAR X + 1 0	511					IN

 $X.X \pm 0.2^{\circ}$ 



**3420 E Ferry Ave. Spokane, WA 99202 ● www.vpiwindows.com** THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. NO PART OF THIS DOCUMENT MAY BE DISCLOSED IN ANY MANNER TO A THIRD PARTY WITHOUT THE PRIOR WRITTEN CONSENT BY VPI QUALITY WINDOWS.

PROJECT SHEET
AC\_PORT\_PROJECT AC\_PANEL\_CLIP\_LOCATION

RE