

SafeGard[™] Provides
Peace Of Mind On
Casement Window
Applications.

SafeGard

CASEMENT-WINDOW
OPENING CONTROL DEVICE

For more information, visit



better from every perspective

700 West Bridge Street Owatonna, MN 55060 **1-800-866-7884** Fax: 507-451-5655 **SafeGard**

CASEMENT-WINDOW
OPENING CONTROL DEVICE

Industry's First Casement — Window Opening Control Device





© 2011 Truth Hardware TRU077



Easy Installation And Operation—

Tested And Certified To ASTM F2090 -10.

SafeGard^m

CASEMENT-WINDOW OPENING CONTROL DEVICE

As a market leader in fenestration hardware, Truth has engineered, patented and manufactured the industry's first casement — Window Opening Control Device (WOCD) that meets the requirements of ASTM F2090-10. This innovative hardware system provides safe and secure operation of egress style windows critical in today's building projects. Multiple safe guards are in place to help control the window opening to prevent accidental falls while at the same time allowing easy operation in the event of an emergency. Typical operation limits the opening of the sash to less than 4". An additional operation is required to open the window fully for egress purposes. This additional operation can be performed without the use of keys, or special tools and the SafeGard™ casement — WOCD will automatically re-latch when the sash is fully closed.



SafeGard™ casement – Window Opening Control Device is tested and certified to ASTM F2090-10

Tested And Certified

The SafeGard™ casement — WOCD is tested and certified to ASTM F2090-10 which is the standard specification for Window Fall Prevention Devices with Emergency Escape (Egress) Release Mechanisms. The ASTM F2090-10 addresses window fall prevention that helps protect against potential falls by children through open windows.

Easy Installation: Designed to allow for factory installation as well as field installation by trained personnel.

Robust Design: Made entirely of austenitic stainless steel and plastic.

Versatile Application: Fits in standard hinge cavity for easy installation.

Easy Operation: No keys or special tools needed.

Operation: 4 Easy Steps



Step 1. Unlock window and crank open to limit.



Step 2. Slide red cover up and hold.



Step 3. Rotate the orange tab toward the exterior (if tab is difficult to rotate, relieve pressure using the crank).



Step 4. Continue to crank window open while holding the orange tab in place, until the window is fully opened.