PAGE: 8 OF 10


NOTE: PLEASE VERIFY ALL HEAD AND SILL HEIGHTS. VPI defines the Rough Opening (RO) as the clear opening after all installation and waterproofing materials are applied. It is critical that the RO is a minimum of ½" larger than the net window frame size for nail flange applications. In the event that your VPI product will be installed with strap anchors, the RO must be 1" larger than the net frame size of the window. VPI shall not be responsible for any incorrect RO sizes.





NAIL FIN - NF





## EXTERIOR ELEVATIONS












18. LC-PG25 (120 X 90) END 4H-SH-AU 19. CW-PG40 (108 X 84) END 4SHA


## INTERIOR ELEVATIONS








PLEASE CONTACT YOUR OUTSIDE SALES REPRESENTATIVE TO ENSUR YOUR EGRESS NEEDS ARE MEET.



PLEASE CONTACT YOUR OUTSIDE SALES REPRESENTATIVE TO ENSUI YOUR EGRESS NEEDS ARE MEET



PLEASE CONTACT YOUR OUTSIDE SALES REPRESENTATIVE TO ENSURE YOUR EGRESS NEEDS ARE MEET.

<b>1</b>	<b>†</b>	<b>†</b>

PLEASE CONTACT YOUR OUTSIDE SALES REPRESENTATIVE TO ENSURE YOUR EGRESS NEEDS ARE MEET.

START DATE:	12/20/23
FINISH DATE:	12/20/23
CHECKED BY:	ENGINEERING
SCALE:	3/32"=1"
DWG BY:	BSP
QUOTE:	
REVISION:	
DAGE Q DE	10